




**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. For outswinging doors, measure, mark and trim rain drip to full width of door. For inswinging doors, trim to clear door stops.
2. Close door and position rain drip along outside bottom edge of door. Be certain rain drip clears threshold (or floor). Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure rain drip to door with supplied screws.